



UNIVERSITÀ DI PISA

Foodback



Sensing how consumers experience Food

Tommaso Califano · Giovanni Ligato · Nicola Ramacciotti · Gabriele Suma


Master's degree in Computer Engineering
Mobile and Social Sensing Systems

Marco Avvenuti · Alessio Vecchio

Why Foodback?

Most dining experiences go unrecorded—people simply don't have the time, interest, or motivation to write **reviews**.

Setting the Table




Yet every bite tells a story



Our goal is to capture that story—**automatically.**

What we Propose

A mobile-based prototype that evaluates food experiences by analyzing *brain* and *body signals*. Bringing objectivity and automation to digital gastronomy.






No user input required





Inside the Feedback Experience






Splash Screen



Login Made Simple

Users can access Foodback's features quickly and securely using just their email and password—nothing more.



Login Screen



No account? No problem.

You can easily register for Foodback anytime through the sign-up page.

A mockup of a mobile app sign-up screen. At the top, there is a back arrow and the text "Create your account". Below this is an illustration of a chef. The main form area is titled "Signup" and "Create your account". It contains several input fields: "Name", "Surname", "Email", "Date of Birth" (with a calendar icon), "Password", and "Confirm Password" (both with eye icons for toggling visibility). There are also radio buttons for "Male" and "Female". At the bottom of the form is a green "Sign Up" button.

← Create your account


Signup
Create your account

☐ Male ☐ Female

Date of Birth

Sign Up

Sign-Up Screen




Evaluation Screen

From Login to Evaluation

After logging in, users are directed to their main dashboard, where the pre-trained machine learning model is ready to evaluate tasting experiences automatically.



Both the EEG cap and the smartwatch must be **connected**—indicated by green icons—before the app allows inference to proceed.




Data Collection Screen

The Secret Ingredient

If the logged-in user is an **Admin**, an alternate route is revealed. Instead of the standard dashboard, the Admin accesses a dedicated **data collection** interface, used to gather EEG and smartwatch signals for training the machine learning model.

This experimental page enables controlled sessions across multiple participants and will be detailed further in the protocol discussion.


SYSTEM ARCHITECTURE




Companion Application



Powered by **WearOS**




Splash Screen



Main Screen

Android Wearable API



- Part of Google Play Services



- Provides a communication channel between wearable devices and connected handheld devices



- Message Client API is a part of the Android Wearable API that enables sending short, one-way, real-time messages between connected devices

MINDROVE SDK



- Mindrove SDK 2.0 for Android



- The **ServerManager** class is responsible for managing a server thread and its interactions.



- **SensorData:**
 - Channel[1-6]
 - NumberOfMeasurements
 - Voltage



TASTING PROTOCOL

1. Device Initialization:



- The protocol begins once EEG and wearable watch (HR & EDA) are connected and ready to transmit data

2. Preparation Phase (5 seconds):



- A first beep signals the subject to bring the food sample into the mouth
- This is a 5-second window to prepare for tasting

3. Recording Phase (10 seconds):



- A second beep marks the start of data recording
- For the next 10 seconds, the system captures EEG, HR, and EDA signals, representing the subject's sensorial response to the food


4. Rating Phase:




- A final beep ends the data capture
- A rating interface appears for the administrator to input the subject's sensorial experience rating




TAUSTING PROTOCOL (2)




Health check on
devices status




Starting the
protocol




Preparation
phase of 5 secs




EEG and Wearable
data recording
phase of 10 secs





TASTING PROTOCOL (3)



Rating the sensorial
experience



Data collected and
session completed



Manage your data
in one-tap



TASTING PROTOCOL

PREVIEW MODE




A **complex** protocol requires **clear** instructions

How do we help subjects understand each step to **optimize** data quality?



Train participants with full protocol exposure



Preview Mode

All steps are performed exactly as in the real session, **but no data is saved**



Identify and fix **signal issues**



Our Homemade Dataset

Small but Gathered with Love

45

TOTAL TASTING SESSIONS


10

PARTICIPANTS

(ages 16–56)

Data collected via the App in Admin mode:


- Manages cues and rating input;
- Streams EEG from MindRove Arc;
- Triggers smartwatch HR and EDA recording;
- Saves one CSV per sensor, preserving native sampling rates.



A bottom sheet lets you delete or share CSV files individually, making it easy to export data for training after experiments.

CSV Management


Pre-Processing



What is an Epoch?

INFO

The epochs form the **input units** for the machine learning model.



1 Experiment \longrightarrow 5 Epochs



The Kitchen-Ready Classifier Adopted




EEGNet

Lawhern et al. (2018)

Compact **CNN** specifically designed for **EEG**.

Tiny two-layer footprint, ideal for **small** EEG datasets

Depthwise convolutions for learning spatial patterns.






Very few details

TENSORFLOW GRAPH EMBEDDED EEG PRE-PROCESSING

All EEG pre-processing steps are fused directly into the TensorFlow model, so no external DSP or signal handling is needed on-device.




Simplifies the deployment on Kotlin



A bit more detail

TENSORFLOW GRAPH EMBEDDED EEG PRE-PROCESSING






A bit more of more detail

TENSORFLOW GRAPH


EMBEDDED EEG PRE-PROCESSING






A bit more of more detail

TENSORFLOW GRAPH EMBEDDED EEG PRE-PROCESSING





MODEL TRAINING & EVALUATION



DEPLOYMENT

Final model exported as a .tflite file, ready for on-device inference via the Feedback app.



A TEMPTING ATTEMPT



But too sweet
to trust

Epoch-Level Split

80/20 split applied randomly across 2-second epochs


73.3 %

TEST ACCURACY

Why it's misleading:


- 🍴 Information leakage from overlapping sessions
- 🍴 Model may memorize session-specific noise or context
- 🍴 Overestimates real-world performance

EVALUATION PROTOCOL



The evaluation phase captures **2-second** samples

EVALUATION PROTOCOL (2)




Health check on
devices status

Preparation
phase of 5 secs

Data collection and
model prediction for 2
secs

Score prediction

FUTURE WORK



A key future goal is to **enhance the application** to automate the full review process and exploring richer output formats (e.g. free-text review generation)



To enhance model **accuracy** and **generalizability**, future work should include data collection from a **larger** and more **diverse** population


CONCLUSIONS



Just a **Prototype**



Observed classification performance reflects the **true complexity** of decoding human taste perception



Technical viability of real-time, on-device inference



*What if a single bite could
speak for itself now?*





What if a single *byte* could
speak for itself now?

Thanks for your attention

