

Paper presentation

Decoding human taste perception by reconstructing and mining temporal-spatial features of taste-related EEGs

Xiuxin Xia · Yuchao Yang · Yan Shi · Wenbo Zheng · Hong Men



PUBLISHED ONLINE
14 March 2024

Professors

Marco Avvenuti
Alessio Vecchio



UNIVERSITÀ DI PISA

Students

Giovanni Ligato
Gabriele Suma



Master's degree in Computer Engineering
Mobile and Social Sensing Systems



Taste is a key factor in consumer decisions and food quality evaluation.

*"Taste isn't merely a flavor;
it's the essence of experience"*



Abstract



Challenge

Traditional taste sensory evaluation, like **human panels** and **electronic tongues**, is prone to subjectivity and limited flexibility.

Goal

Decode objective taste perception by analyzing EEG signals corresponding to **sour**, **sweet**, **bitter**, and **salty** tastes.

Results

TSRDA&TSCNN-CA provides an objective and effective method for the sensory evaluation of food taste.

- Accuracy: 99.56%
- F1 score: 99.48%
- Kappa Value: 99.38%


TSRDA&TSCNN-CA

What!?



Temporal and Spatial Reconstruction Data Augmentation


Enhances the limited EEG dataset by reconstructing key features in both time and channel dimensions.



Temporal and Spatial **CNN** with Channel Attention

A specialized CNN designed to extract both temporal and spatial patterns from the augmented EEG data for reliable taste classification.

What!?




Experiments for **Data** collection

Collect taste related EEGs under controlled taste stimuli.



Temporal and Spatial **Reconstruction** **Data Augmentation**

Enhances the limited EEG dataset by reconstructing key features in both time and channel dimensions.



Temporal and Spatial **CNN** with **Channel Attention**

A specialized CNN designed to extract both temporal and spatial patterns from the augmented EEG data for reliable taste classification.




Experimental Setup



10 males

Participants

nonsmoking subjects
ages 20–30



10 females

Pre-experiment Instructions



Wash hair



Brush teeth using
unscented toothpaste



No food for 2 hours
before the experiment



Water allowed

Why?

To ensure **consistency** in physiological state and **minimize** interference.

Taste Stimuli



Sweet



Salty



Sour



Bitter




Record the **EEG** responses induced by each taste.

Solutions prepared according to previous studies.



This Ensures that each solution is **clearly** perceived **without discomfort**.

Taste-Evoker



Self-Developed



Low-Noise



High-Precision and
High-Stability

EEG Acquisition




NCERP-P EEG
Acquisition System



256 Hz
Sampling Frequency




21-channel EEG cap
Electrode Setup



Environment
 $21 \pm 2^\circ\text{C}$

Pre-Experiment Setup



Minimal
Electromagnetic Interference

4 days
EACH DAY
Subjects randomly receive all 4
taste stimulations.



Randomized taste selection
ensures unbiased stimulation.

Taste solution delivered via
the evoker: tube positioned
0.25–0.5 cm above tongue.

Subjects keep their eyes closed
to avoid seeing the solution.

Stimulation
Protocol



Subject wears EEG cap,
earplugs, nasal plugs, and
uses a chin rest.



Preprocessing

10s
Duration of each recorded
segment during taste stimulation



Data Segmentation


Each segment divided
into 5 samples (2s each)



Days
Segmentation
Subjects
Tastes

$$20 \times 4 \times 4 \times 5 = \text{1600 EEG samples}$$

TOTAL




MATLAB

Preprocessed by MATLAB and its
built-in toolkit **EEGLAB**.




The final size of a taste-related
EEG sample was 256×21
W H

Filtering & Downsampling



Bandpass Filtering

Removes low/high-frequency noise



Notch Filtering

Eliminates power line interference



From 256 Hz



To 128 Hz

Downsample

To reduce sample size


TS@RDA

Temporal and Spatial Reconstruction
Data Augmentation



CNNs require large amounts of data.

However, taste-related EEG datasets are generally **limited** due to **experimental complexities**.



Training Challenge



Solution




Data Augmentation

Increasing the diversity and volume of training data is critical to enhance model performance and avoid overfitting.





Enhances diversity in both **temporal** and **spatial** features.

Ingredients




Pre-Processed
Dataset

Associated Label




Recipe

1. **Randomly** select two **EEG** samples from the Pre-Processed **Dataset**




Sweet




Sour

Recipe

2. From both samples, cut an **identically sized** data block of dimensions $w \times h$ from the **same location**.




Sweet



Sour

Recipe

3. Insert the data block from the second sample into the first sample to create a **newly reconstructed sample**.



Sweet

~ 0.81



Sour

~ 0.19

The new sample is assigned **two labels**, with each label's weight **proportional to the area** of the corresponding data block. During model training, these two labels are optimized according to their respective weights.

Recipe

Block Extraction Details


The **location** and **size** of the data blocks are not arbitrary

They are determined through **hyperparameter optimization** to maximize TSRDA's effectiveness.



The **centers** of the cutting blocks are:

- **Evenly** distributed along the **temporal** dimension;
- Mainly in the **lower half** of the EEG channels (**spatial**).



The dimensions w and h are **uniformly distributed** over their respective ranges, $[0, W]$ and $[0, H]$.

TSCNN-ca

Temporal and Spatial **CNN** with
Channel **A**ttention




Multi-View Channel Attention




Objective

Empower the CNN to focus on essential EEG features while minimizing redundancy.



TSCNN-CA




CNNs

Have excelled in EEG classification by extracting rich, high-dimensional features.

TSCNN-CA

Integrates both **temporal** and **spatial** convolutions to capture crucial patterns in taste-related EEG signals.


The background is a light blue color with a large, irregular white shape in the center. In the top-left and bottom-left corners, there are yellow circles. Three kiwi slices are illustrated: a large one in the top-left, a large one in the bottom-right, and a smaller one in the bottom-left. The kiwi slices are green with a yellow center and brown seeds.

Results and discussion

Taste-related EEG topographic map

Brain response under different stimuli

The average EEG topographic maps recorded under different taste stimuli reveal distinct patterns of brain electrical activity, indicating significant variation depending on the type of stimulus.



Sweet taste shows enhanced electrical activity in the parietal and temporal lobe regions



Bitter and sour taste shows pronounced electrical activity in the frontal, occipital and temporal lobes.





Salty taste primarily activated portions of the parietal and temporal lobe regions



Water triggers less brain activity than other tastes

EEG Topography Maps



Taste-related EEG experimental settings

■ Experimental test and evaluation metrics

Taste-related EEG four-classification experiments for subject independence and subject non-independence were performed.

■ Subject independence

Taste-related EEG samples of each subject were the test set, and the other subjects were the training set.

■ Subject non-independence

A total of 1600 taste-related EEG samples from 20 subjects were randomly divided into training and test sets at 3:1.

■ Model Hyperparameter


Expansion multiple of the TSRDA to the training set was 3. Training set batch size 64 and test set batch size 32. Optimizer used Adam, number of epochs 100, learning rate 0.0005 and weight decay was 0.001.

Effectiveness analysis of TSRDA

Evaluation index	Before augmentation	After augmentation
Accuracy \pm std (%)	98.10 \pm 2.03	99.56 \pm 0.21
F1-Score \pm std (%)	98.09 \pm 2.04	99.48 \pm 0.31
Kappa \pm std (%)	97.39 \pm 2.77	99.38 \pm 0.29



Comparison with state-of-art models

Reference	Augmentation method	Classification method
25	Add Gaussian noise	ResNet
26	Time division and reorganization	Shallow CNN
27	Brain area recombination	EEGNet
37	Sliding time windows segmentation	VGG-16
28	Sliding time windows segmentation	Deep CNN
29	CutCat	Deep CNN
This Paper	TSRDA	TSCNN-CA



Most techniques only focus on either **temporal or spatial dimensions**, not fully preserving the important **local features**.

TSRDA: Data augmentation multiple




TSRDA and MVCA

● TSCNN **VS** TSCNN-CA

The introduction of MVCA method can better mine the important features of taste-related EEGs, avoiding redundant information.

● Raw **VS** TSRDA

TSRDA effectively augmented the raw training set, improving the recognition accuracy and stability of taste-related EEGs.



Subject-independent test

Challenges



Stability




**Generalization
ability**




**Individual
differences**




t-SNE Visualization of test set




Raw & TSCNN



Raw & TSCNN-CA




TSRDA & TSCNN-CA




*Future directions
and critical analysis*

Limitations and future directions



Dataset scale & Universality

Increasing the subject pool is crucial for **broader applicability**. Cross-subject EEG recognition **remains a significant challenge**.



Data Acquisition Challenges

Taste-related EEG collection is costly and time-consuming, limiting dataset size. **TSRDA** offers a promising solution to **augment limited data**, though it may sometimes introduce **redundant information**.

Limitations and future directions



Enhancing Feature Extraction:


The **MVCA** module effectively mitigates **redundant information**, improving feature discrimination. Future work will explore applying these methods to **other EEG tasks**.



Automation & Optimization:

Currently, TSRDA relies on manual selection for reconstructing optimal temporal-spatial features. Integration of automatic methods (e.g., Grad-CAM) is planned to streamline reconstruction and boost effectiveness.

Is the experiment reliable?



■ Data split ambiguity:

The paper only discusses training and test sets, there is no explicit mention of a distinct validation set.

■ Hyperparameter Tuning Uncertainty:

It's unclear whether hyperparameter tuning was performed on a separate validation subset.




Without a dedicated validation set, it's uncertain if the model's tuning and performance measures were optimally evaluated.



This may affect the reported generalizability of the results.



Conclusions



Conclusions




Robust EEG Acquisition:

An experimental paradigm was established that effectively acquired taste-related EEGs induced by sour, sweet, bitter, and salty tastes.



Effective Data Augmentation (TSRDA)

An experimental paradigm was established that effectively acquired taste-related EEGs induced by sour, sweet, bitter, and salty tastes.



Superior Classification (TSCNN-CA with MVCA):

Combining TSRDA with the TSCNN-CA—enhanced by a multi-view channel attention (MVCA) module—ensures comprehensive model training and effectively mitigates redundant information for accurate taste decoding.



Overall Impact & Limitations

The combined approach outperforms state-of-the-art methods in decoding EEG signals for the four basic tastes. Although effective for basic tastes, the method does not yet accommodate mixed flavours—an area targeted for future research.



Thanks
for your attention